

»»» HL31/HL60/HL71 »»» LONG-RANGE SERIES HEADLIGHTS

NOTICE:

- 1.In order to bring you a better user experience, after receiving the new product, it is recommended to fully charge before using it.
- 2.This product is not a toy, please keep it away from children, and do not direct light to people's eyes, so as not to affect vision.
- 3.When installing, please install the battery in the correct direction ("+" means positive and "-" means negative), and the battery is strictly prohibited to be installed backwards. When a single battery is reversed, the electric display indicator flashes directly to prompt, and when two batteries are reversed, the product cannot be used
4. All the product parameters provided in this manual are tested by our company's laboratory standard samples and are for reference only, and may vary slightly due to different samples and environments.

PRODUCT PARAMETERS

Model	HL31	HL60	HL71
Power	36W	36W	15W
Charging ways	Type-C	Type-C	Type-C
Distance	320M	400M	300M
Size	L69*Φ45MM	76*43*102MM	L55*Φ40MM

NOTE: The above data are provided by the company lab for reference only.

INSTRUCTION FOR HL31



- 1.Turn on the light source: Press the switch button of the lamp head to turn on the low light mode, and at the same time the red indicator light in the battery compartment is on, and continue to press the mode adjustment (low light-medium light-strong light-strobe-off) to sequentially adjust the mode. Press and hold any light source position for about 2 seconds to turn off the light source.
2. Power display: four-segment electric display design, the remaining power display is more accurate, and the use is more assured.
3. The blue indicator light flashes when charging, and the blue indicator light is always on when it is fully charged.

INSTRUCTION FOR HL60



- 1.Turn on the light source: Press the switch button of the lamp head to turn on the light source, that is, the low light mode, and continue to press the adjustment mode (low light-medium light-strong light-strobe-off) to sequentially adjust the mode. Press and hold any light source position for about 2 seconds to turn off the light source.
2. Power display: four-segment electric display design, the remaining power display is more accurate, and the use is more assured
3. The blue indicator light flashes when charging, and the blue indicator light is always on when it is fully charged.

INSTRUCTION FOR HL71



- 1.Turn on the light source: Press the switch button of the lamp head to turn on the strong light mode, continue to press the shift (strong light-medium light-olight-strobe-SOS-off) to sequentially adjust the mode; the mode position (strong-medium-low) long press Turn on the induction mode in about 2 seconds (hand sweep can switch the light source), and the light source will flash once to indicate that it is turned on. Keep pressing to turn off the light source and sensor mode.
- 2.Power display: four-segment electric display design, the remaining power display is more accurate, and the use is more assured.